




SANYO
PORTABLE RADIO
CASSETTE RECORDER
M9800TU
SERVICE MANUAL



SPECIFICATIONS

Recording system	AC bias, double track
Erasing system	AC erase
Tape speed	1-7/8 ips. (4.75 cm/s)
Rewind & Fast forward time	1'30" (C-60)
Speed accuracy	±2%
Frequency response	80 – 10,000 Hz ±6dB
Signal to noise ratio	45dB
Wow & Flutter	0.3% RMS
Terminal impedance	EXT MIC: 15K ohms DIN input 3K ohms output 1K ohms EARPHONE: 8 ohms
Frequency range	AM: 510 – 1605 KHz LW: 150 – 350 KHz SW1: 2.3 – 7.0 MHz SW2: 7.0 – 22.0 MHz FM: 87.5 – 108 MHz
Power output	TWEETER: 650mW WOOFER: 3W
Current consumption	PLAY: less than 167mA REW & F.FWD: less than 230mA
Power consumption	12W
Power source	DC: 9V D cell x 6 AC: 115/230V 50/60Hz
Dimensions	14-9/16"(W) x 4-1/4"(D) x 9-7/16"(H) (372 x 108 x 240mm)
Weight	Approx. 8 lbs. 7 oz. (3.9 Kg) excluding batteries

- Measure the each torque with a torque gauge. They should be as following;

PLAY	30 – 60g/cm
FAST FORWARD	60 – 110g/cm
REWIND	60 – 110g/cm

- If the each torque fails to reach the standard value. Clean the drive belt, flywheel, motor pulley, take-up reel, idler and rewind roller with a cotton swab soaked in alcohol.

ADJUSTMENT OF HEAD AZIMUTH

- Connect the unit to a power source and insert a test cassette tape (7K Hz pre-recorded) in the cassette compartment.
- Connect an 8 ohm dummy load with the VTVM across it to the EXT. SP jack on the unit.
- Set the unit into the PLAY mode.
- Turn the head azimuth adjusting screw until the maximum value with reading on the VTVM.
- Fasten the adjusting screw securely by applying paint or glue.




Fig. 2

ADJUSTMENT OF PINCH ROLLER

- Set the unit to the PLAY mode.
- Apply a tension gauge to the pinch roller. Read the gauge at the precise moment when the pinch roller separates from the capstan.
- If the gauge reading is within a range of 450 – 650g, no adjustment is necessary. If otherwise, make adjustment by changing the force of the spring coil. (See exploded view No. 24)




Fig. 1

TORQUE ADJUSTMENT

- Set the unit to the PLAY, FAST FORWARD or REWIND mode.

LW ALIGNMENT

Step	Adjusting Circuit	Connections		SG frequency	Position of tuning dial	Adjustment	VTVM Oscilloscope
		Input	Output				
1	O.S.C.	Connect AM SG. to Test Loop.	Connect VTVM to speaker terminals.	145kHz (400Hz 30% modulation)	Low end of dial scale	L118	MAX.
2				365kHz (400Hz 30% modulation)	High end of dial scale	CT10	
3	ANT.	Connect AM SG. to Test Loop.	Connect VTVM to speaker terminals.	160kHz (400Hz 30% modulation)	160kHz on dial scale	L111-2	MAX.
4				340kHz (400Hz 30% modulation)	340kHz on dial scale	CT9	
5	Repeat adjustments.						

AUTO-STOP ADJUSTMENT

Measure the sensor pressure with a tension gauge with the unit set in the playback mode. The unit should be shut off when the sensor pressure stand within a range of 30 to 55 grams. (Fig. 3)
If the shut-off mechanism fails to function at a sensor pressure of 30 to 55 grams, adjust the spring coil (Mechanism No. 73).






Fig. 3

TUNER ADJUSTMENT

FM ALIGNMENT

Step	Adjusting Circuit	Connections		SG frequency	Position of tuning dial	Adjustment	VTVM Oscilloscope
		Input	Output				
1	I.F.	Connect sweep generator to Ⓜ VC1, Ⓜ TP2	Connect oscillo- scope to Ⓜ R332, Ⓜ Shield plate	10.7 MHz (none modulation)	Near max. capacity of VC. at position with no unrequired signal.	T301, T302	
2	Ratio Det.					T303	
3	O. S. C.	Connect FM SG. to Ⓜ TP3 Ⓜ TP2	Connect VTVM to speaker terminal.	87 MHz (400 Hz 30% modulation)	Low end of dial scale	L104	Max.
4				109 MHz (400 Hz 30% modulation)	High end of dial scale	CT2	
5	ANT	Connect FM SG. to Ⓜ TP3 Ⓜ TP2	Connect VTVM to Speaker terminal.	90 MHz (400 Hz 30% modulation)	90 MHz on dial scale	L102	Max.
6				108 MHz (400 Hz 30% modulation)	108 MHz on dial scale	CT1	
7	Repeat adjustments.						

- PREPARE: 1. Variable Capacitors completely closed.
 2. Set the dial pointer to very left line of dial scale.
 3. Connect sweep generator, FM SG. VTVM and oscilloscope. FM aerial input impedance is 75 ohm.
 4. Use a screwdriver with plastic grip for all adjustments.

AM ALIGNMENT

AM ALIGNMENT							
Step	Adjusting Circuit	Connections		SG frequency	Position of tuning dial	Adjustment	VTVM Oscilloscope
		Input	Output				
1	I. F.	Connect sweep generator to TEST LOOP.	Connect oscilloscope to EXT. SP.	460 KHz (400 Hz 30% modulation)	Low end of dial scale at position of no un-required signal.	T304,305	Max.
2	O. S. C.	Connect AM SG. to TEST LOOP.	Connect VTVM to EXT. SP. terminals	505 KHz (400 Hz 30% modulation)	Low end of dial scale	L117	Max.
3				1650 KHz (400 Hz 30% modulation)	High end of dial scale	CT4	
4	AERIAL	Connect AM SG. to TEST LOOP .	Connect VTVM to EXT. SP. terminals.	600 KHz (400 Hz 30% modulation)	600 KHz on dial scale	L111-1	Max.
5				1400 KHz (400 Hz 30% modulation)	1400 KHz on dial scale	CT3	
6	Repeat adjustment						

- PREPARE: 1. Variable capacitor completely closed.
 2. Set the dial pointer to very left line on dial scale.
 3. Use a screwdriver with plastic grip for all adjustments.
 4. Selector switch to "AM".

SW1 ALIGNMENT

SWT ALIGNMENT

Step	Adjusting Circuit	Connections		SG frequency	Position of tuning dial	Adjustment	VTVM Oscilloscope
		Input	Output				
1	O.S.C.	Connect AM SG. to ANT terminal through IRE dummy.	Connect VTVM to EXT. SP. terminals.	2.2MHz (400Hz 30% modulation)	Low end of dial scale	L116	MAX.
2				7.2MHz (400Hz 30% modulation)	High end of dial scale	CT8	
3	ANT.	Connect AM SG. to ANT terminal through IRE dummy.	Connect VTVM to EXT. SP. terminals.	2.5MHz (400Hz 30% modulation)	2.5MHz on dial scale	L110	MAX.
4				6.5MHz (400Hz 30% modulation)	6.5MHz on dial scale	CT6	
5	Repeat adjustments.						

- PREPARE: 1. Set the dial pointer to very left line dial scale.
 2. Connect signal generator to dummy antenna.
 3. Use screwdriver with plastic grip for all adjustments.
 4. Selector switch to "SW1".

SW2 ALIGNMENT

Step	Adjusting Circuit	Connections		SG frequency	Position of tuning dial	Adjustment	VTVM Oscilloscope
		Input	Output				
1	O.S.C.	Connect AM SG. to ANT terminal through IRE dummy.	Connect VTVM to EXT. SP terminals.	6.8MHz (400Hz 30% modulation)	Low end of dial scale	L115	MAX.
2				22.7MHz (400Hz 30% modulation)	High end of dial scale	CT7	
3	ANT.	Connect AM SG. to ANT terminal through IRE dummy.	Connect VTVM to EXT. SP.terminal	8.5MHz (400Hz 30% modulation)	8.5MHz on dial scale	L109	MAX.
4				21.0MHz (400Hz 30% modulation)	21.0MHz on dial scale	CT5	
5	Repeat adjustments.						

PREPARE: 1. Set the dial pointer to very left line dial scale. 2. Connect signal generator to dummy antenna. 3. Use screwdriver with plastic glip for all adjustments. 4. Selector switch to "SW2".

PARTS LIST

Key No.	Part No.	Description	Q'ty
PACKING			
	141-6-144T-25200	Styrol filler, Right side	1
	141-6-144T-25300	Styrol filler, Left side	1
	141-6-132T-63303	Individual carton	1
	141-6-411T-71202	Instruction bookletä	1
	123-6-453R-00100	Inspection sheet	2
	141-6-472T-05602	Caution label, Voltage indicate	1
		Polyethylene bag 400 x 550mm, Set	1
		Polyethylene bag 200 x 350mm, Inst B	1
	141-6-415T-12100	Notice, Swedish	1
ACCESSORIES			
	4-241T-11171	P' ssette tape C-12	1
	4-243T-77900	Power supply cord	1
	4-236T-09700	Plug, Eraser	1
CABINET			
	141-0-111T-248912	Cabinet assembly	1
	141-0-124T-117910	Top lid assembly	1
	141-0-126T-156914	Back lid assembly	1
	141-0-128T-08291	Battery lid assembly	1
	141-2-851T-87900	Coil spring, Top lid opener	2
	141-2-751T-46200	Shaft, Top lid fulcrum	1
	141-2-741T-78100	Lever, EJECT	1
	141-2-161T-25000	Push button, DL	1
	123-2-472R-11100	Lug, Rod antenna	1
	141-2-157T-21100	Inlay, Mechanism button STOP/REW/PLAY/F.FWD	4
	141-2-157T-21101	Inlay, REC	1
	141-2-157T-21200	Inlay, PAUSE	1
	141-2-741T-85600	Lever, Chrome select	1
	141-2-851T-93600	Coil spring, Chrome select	1
	141-0-163T-27191	Rotary knob assembly, Tuning	1
	141-2-163T-27200	Rotary knob, Main VR	1
	141-2-163T-27300	Rotary knob, TONE Woofer Tweeter	3
	141-2-134T-07500	Head cover	1
	141-2-163T-32000	Rotary knob, Fine tuning	1
	141-6-479T-16800	Label, FTZ No.	1
CHASSIS			
	141-0-311T-194911	Chassis assembly	1
	141-0-566T-02600	Tuning shaft assembly	1
	123-2-415R-10100	Nut, Tuning shaft mtg.	1
	141-2-853T-39400	Plate spring, REC select	1
	141-2-851T-06300	Coil spring, Rope	1
	141-2-538T-03900	Drum, VC mtg.	1
	141-2-425T-00200	Hexagon screw, VC mtg.	1
		Dial rope 0.5 x 1200mm	1
	141-2-146T-05702	Dial scale	1

Key No.	Part No.	Description	Q'ty
CHASSIS			
	141-2-245T-00900	Back plate	1
	141-2-135T-39900	Cover, Dial scale mtg.	1
	141-0-511T-01900	Pointer assembly	1
	141-0-747T-12691	Bracket assembly, RADIO ON/OFF select	1
	123-2-445R-01400	Cushion ring, PL mtg.	1
	141-2-385T-02200	Bracket, MIC mtg.	1
	141-2-365T-32300	Bracket, Micro switch mtg.	1
	141-2-853T-43100	Plate spring, Bracket mtg.	1
	123-2-472R-00400	Lug	2
	141-2-853T-44900	Plate spring, Bracket mtg.	1
	141-2-337T-01600	Ribbon, Battery take up	1
		Fiber washer 4 x 10 x 1mm, Ribbon mtg.	1
	141-2-322T-13900	Shield plate, P.C.B. mtg.	1
	123-2-472R-00600	Lug, PT mtg.	1
	141-2-241T-14300	Veil, Switch mtg.	2
		Rubber cushion 3.3 x 8 x 1mm, Mechanism	3
	141-2-421T-12300	Special screw, Slide mtg.	2
	141-2-731T-39400	Slide, Radio ON/OFF select	1
	141-6-479T-11800	Label, Fuse	1
ELECTRICAL PARTS			
		AMP	
	4-511T-06400	Meter	1
	4-151T-20200	Speaker, Woofer 16cm 8 ohms	1
	4-151T-17800	Speaker, Tweeter 5cm 8 ohms	1
	4-153T-09500	Condenser microphone	1
	4-251T-51200	Power transformer 115/230V	1
S731,732	4-231T-50700	Switch, Dial lamp & Batt.	1
PL701	4-612T-06974	Pilot lamp, Dial 100mA/6V	1
	4-235T-12171	Socket, Car battery	1
	4-231T-37604	Switch, Voltage select	1
	141-2-135T-32271	Cover, AC socket	1
	4-235T-26900	Socket, AC input	1
	4-234T-03100	Fuse 1.25A	1
	141-2-383T-01500	Fuse holder	1
S761	4-231T-506911	Switch assembly	1
	4-243T-12805	Lead, SP UL1007 360mm	2
		Orange & Yellow	
	4-231T-39771	Switch, Normal/CrO ₂ select	2
		TUNER	
	4-244T-01100	Rod antenna	1
VC5	4-243T-12803	Lead, Rod antenna	1
	4-224R-20100	Fine tuning	1

PARTS LIST

Key No.	Part No.	Description	Q'ty
PRINTED CIRCUIT BOARD ASSY (AMP)			
L701 L703 L705 SVR701	4-226T-75892	Printed circuit board assembly, AMP	1
	4-254T-13600	Output transformer, Woofer AMP	1
	4-254T-13700	Input transformer, Woofer AMP:	1
	4-254R-02300	Input transformer, Tweeter.	1
	4-252T-02300	Choke coil 15mH, Bias trap	1
	4-253T-04200	Choke coil 6.8mH, High boost	1
	4-252T-02200	Choke coil 100μH, Motor	1
	4-222R-60900	Semi-variable resistor 50KB, Bias adjust	1
	4-231T-21572	R/P switch	1
	S701 ~ S712 S801 ~ S806	4-231T-51500	Switch, Radio/Tape/Sleep
Q701 Q704 Q705,706 Q707,708 Q709 IC701 IC702 IC703 D701,702 D703,704 D705 D706 D707,708 709	4-235T-33671	Socket assembly, Earphone AUX. MIC.	1
	4-231T-42100	Beat cancel switch	1
	141-2-461T-02800	Pipe, L703 & L705 mtg.	2
	141-2-382T-03071	Terminal tip, SP lead terminal	2
	141-2-368T-08900	Heat sink	1
		Fiber washer 3.3 x 8 x 0.5mm,	1
		Heat sink	1
		Transistor 2SC1571	1
		Transistor 2SC536AUD	1
		Transistor 2SD400	2
C701,733 C737,761 769 C703,706 719,736 C725,726 743,763 778 C714 C724 C709 C745 C710 C739,753 755 C760 C727,738 C746,747 C754 C768 C716 C712 C718 C717 C748,749 751,752 C722,779 780 C720 C762,774 C702 C767 C771 C704 C723 C705,715 773 C713 C772 C756,757 758,759 C790 C750		Transistor 2SC1568	2
		Transistor 2SD400	1
		IC BA313	1
		IC BA318	1
		IC BA306	1
		Diode 1S188 FM-1	2
		Diode 1S188 AM	2
		Diode DS131	1
		Diode DS132	1
		Diode MA-26	3
CAPACITORS			
		Electrolytic 0.1μF +40 -20%, 10WV	2
		Electrbytic 2.2μF +100 -10%, 25WV	3
		Electrolytic 4.7μF +100 -10%, 16WV	4
		Electrolytic 10μF +100 -10% 16WV	5
		Electrolytic 22μF +100 -10% 10WV	1
		Electrolytic 33μF +100 -10% 6.3WV	1
		Electrolytic 100μF +100 -10% 10WV	1
		Electrolytic 220μF +100 -10%, 6.3WV	1
		Electrolytic 220μF +100 -10% 10WV	1
		Electrolytic 220μF +100 -10% 16WV	3
		Electrolytic 330μF +100 -10% 16WV	1
		Electrolytic 470μF +100 -10% 10WV	2
		Electrolytic 1000μF +100 -10% 16WV	2
		Electrolytic 2200μF +100 -10% 16WV	1
		Mylar 470pF ±20% 50WV	1
		Mylar 680pF ±10% 50WV	1
		Mylar 680pF ±20% 50WV	1
		Mylar 820pF ±20% 50WV	1
		Mylar 0.0015μF ±20% 50WV	1
		Mylar 0.0068μF ±20% 50WV	4
		Mylar 0.01μF ±20% 50WV	3
		Mylar 0.018μF ±10% 50WV	1
		Mylar 0.022μF ±20% 50WV	2
		Mylar 0.068μF ±20% 50WV	1
		Mylar 0.0082μF ±20% 50WV	1
		Mylar or Ceramic 0.0022μF ±20% 50WV	1
		Mylar or Ceramic 0.0047μF ±20% 50WV	1
		Ceramic 10pF ±10% 50WV	1
		Ceramic 100pF ±10% 50WV	1
		Ceramic 150pF ±10% 50WV	1
		Ceramic, 330pF ±20% 50WV	1
		Ceramic 0.04μF +80 -20% 50WV	4
		Ceramic 120pF ±10% 50WV	1
		Mylar 0.047μF ±20% 50WV	1

Key No.	Part No.	Description	Q'ty
PRINTED CIRCUIT BOARD ASSY (AMP)			
RESISTORS			
R762		Winding wire 0.5 ohm ±10% 1/2W	1
R777,778		Carbon 1 ohm ±10% 1/4W	2
R771		Carbon 6.8 ohm ±10% 1/4W	1
R714		Carbon 10 ohm ±10% 1/4W	1
R758		Carbon 15 ohm ±10% 1/4W	1
R763		Carbon or Solid 18 ohm±10% 1/2W	1
R780		Carbon or Solid 27 ohm±10% 1/2W	1
R789		Carbon 39 ohm ±10% 1/4W	1
R766		Metal oxide film 47 ohm±10% 1W	1
R759		Carbon or Solid 100 ohm±10% 1/2W	1
R706		Carbon 150 ohm ±10% 1/4W	1
R723		Carbon 270 ohm ±10% 1/4W	1
R765		Carbon or Solid 330 ohm±10% 1/2W	1
R727,779, 733		Carbon 390 ohm ±10% 1/4W	3
R755,761 774,776		Carbon 470 ohm ±10% 1/4W	4
R781		Carbon 560 ohm ±10% 1/4W	1
R723,719 773,775		Carbon 680 ohm ±10% 1/4W	4
R710,756 784		Carbon 1K ohm ±10% 1/4W	3
R785		Carbon 100 ohm ±10% 1/4W	1
R794		Carbon 120 ohm ±10% 1/4W	1
R731,760 788		Carbon 1.5K ohm ±10% 1/4W	3
R732,782		Carbon 2.2K ohm ±10% 1/4W	2
R720		Carbon 2.7K ohm ±10% 1/4W	1
R721,730, 701,736		Carbon 3.3K ohm ±10% 1/4W	4
R707,717 722,772		Carbon 3.9K ohm ±10% 1/4W	4
R797		Carbon 4.7K ohm ±10% 1/4W	1
R713		Carbon 5.6K ohm ±10% 1/4W	1
R712,718 726,702		Carbon 6.8K ohm ±10% 1/4W	4
R705,708		Carbon 10K ohm ±10% 1/4W	2
R709		Carbon 15K ohm ±10% 1/4W	1
R734,796		Carbon 18K ohm ±10% 1/4W	2
R728,735		Carbon 22K ohm ±10% 1/4W	2
R770		Carbon 27K ohm ±10% 1/4W	1
R724		Carbon 150K ohm ±10% 1/4W	1
R729		Carbon 39K ohm ±10% 1/4W	1
R716		Carbon 56K ohm ±10% 1/4W	1
R783,767		Carbon 68K ohm ±10% 1/4W	2
R715 769		Carbon 100K ohm ±10% 1/4W	2
R704		Carbon 1M ohm ±10% 1/4W	1
PRINTED CIRCUIT BOARD ASSY (VR)			
	4-226T-844910	Printed circuit board assembly, VR	1
S781,782	4-231T-478911	Switch assembly, Loudness, AFC	2
VR704	4-222T-43571	Variable resistor 50KA, Tweeter	1
VR701,703	4-222T-43671	Variable resistor 50KA,Woofer and TONE	2
VR702	4-222T-43771	Variable resistor 50KB, Volume	1
Q702,703	4-258T-13101	OSC pack	1
		Transistor 2SC1571	2
CAPACITORS			
C728,731 740,742		Electrolytic 4.7μF +100 -10% 16WV	4
C733		Electrolytic 0.1μF +40 -20% 10WV	1
C729		Electrolytic 100μF +100 -10% 6.3WV	1
C735		Mylar 0.0068μF ±20% 50WV	1
C732		Mylar 0.047μF ±20% 50WV	1
C734,770		Mylar 0.068μF ±20% 50WV	2
C730,741		Ceramic 100pF ±10% 50WV	2
C770		Mylar 0,082μF ±20% 50WV	1
RESISTORS			
R740,750		Carbon 150 ohm ±10% 1/4W	2
R739		Carbon 390 ohm ±10% 1/4W	1
R751		Carbon 1.5K ohm ±10% 1/4W	1
R742,745		Carbon 2.2K ohm ±10% 1/4W	2

PARTS LIST

Key No.	Part No.	Description	Q'ty
PRINTED CIRCUIT BOARD ASSY (VR)			
R738,743 754		Carbon 2.7K ohm $\pm 10\%$ 1/4W	3
R753		Carbon 3.3K ohm $\pm 10\%$ 1/4W	1
R741		Carbon 4.7K ohm $\pm 10\%$ 1/4W	1
R744,752		Carbon 6.8K ohm $\pm 10\%$ 1/4W	2
R791		Carbon 27K ohm $\pm 10\%$ 1/4W	1
R749		Carbon 270K ohm $\pm 10\%$ 1/4W	1
R737		Carbon 820K ohm $\pm 10\%$ 1/4W	1
PRINTED CIRCUIT BOARD ASSY (TUNER)			
	4-226T-840913	Printed circuit board assembly, TUNER	1
	4-226T-88300	Printed circuit board, SWITCH	1
	141-2-382T-03000	Terminal, TP1,2 & Fine tuning	4
	4-237T-00100	Terminal, TP3,4 & Other connections	10
	123-2-471R-10900	Core, Q103 emitter	1
	123-2-471R-10400	Core, Q104 emitter	1
L102	4-265R-00300	V.H.F coil	1
L103,114	4-265R-12700	V.H.F coil	2
L104	4-265T-02600	V.H.F coil	1
L105	4-252T-05900	Choke coil 18 μ H	1
L106	4-252T-06300	Choke coil 150 μ H	1
L107	4-253R-11100	Choke coil 1 μ H	1
L109	4-257R-26930	Antenna coil	1
L110	4-257T-16000	Antenna coil	1
L111-1.2	4-257T-15901	Antenna coil assembly	1
L113	4-265R-00600	V.H.F coil	1
L115	4-258T-07500	OSC coil	1
L116	4-258T-07600	OSC coil	1
L117	4-258T-05640	OSC coil	1
L118	4-258T-05540	OSC coil	1
L119	4-265R-05000	V.H.F coil	1
L120	4-265R-11200	V.H.F coil	1
VC1-4	4-224T-04600	Variable Capacitor 20 — 335pF	1
CT1-4			
CT5,6	4-224R-01400	Trimmer 8pF	4
7,8	4-224R-01471	Trimmer 16pF	2
CT9,10	4-224R-01600	I.F.T, FM gray	1
T301	4-256T-05140	I.F.T, FM pink	1
T302	4-256T-04540	I.F.T, FM sky blue	1
T303	4-256T-04040	I.F.T, AM 460 Hz	1
T304	4-256T-80300	I.F.T, AM black	1
T305	4-256T-03740	R.F filter FF88 108M, B.P.F	1
	4-253T-09200	Pan head screw 2.6 x 4mm	2
CF301,302	4-256T-80400	red	
	4-256T-80471	blue	
	4-256T-80472	orange	
	4-256T-80473	black	
	4-256T-80474	white	
S1	4-231T-55791	I.F filter SFE10.7M	2
SVR301	4-222R-61100	Push switch assembly, Band select	1
	141-2-322T-18900	Variable resistor 5KB	1
	123-2-445R-00200	Shield plate, P.C.B mtg.	1
	141-2-322T-29800	Rubber cushion, VC mtg.	1
	141-2-322T-29900	Shield plate, P.C.B mtg.	1
		Shield plate, P.C.B mtg.	1
Q101,302		Transistor 2SC930	3
304			
Q102,103		Transistor 2SC929	5
301,303		Diode 1S188 FM	
305			
Q104		Diode 1S553	1
D101,303		Diode 1S2473	2
304		Diode DS442	1
D102		Diode 1S188 AM	3
D103,104			
D105		Diode MV-11T	1
D106,301		Diode 1S188 FM-1	2
302		Diode YZ047A	1
D305			
D306,307			
D308			


Key No.	Part No.	Description	Q'ty
PRINTED CIRCUIT BOARD ASSY (TUNER)			
CAPACITORS			
C316,333		Electrolytic 0.1 μ F +40 —20% 10WV	2
C123		Electrolytic 0.47 μ F +40 —20% 10WV	1
C322,328		Electrolytic 4.7 μ F +150 —10% 25WV	2
C308		Electrolytic 10 μ F +100 —10% 16WV	1
C334		Electrolytic 330 μ F +100 —10% 6.3WV	1
C340		Electrolytic 0.1 μ F +40 —20% 10WV or Semi-conductor ceramic 0.1 μ F +80 —20% 12WV	1
C132		Styrol 180pF $\pm 5\%$ 50WV	1
C131		Styrol 350pF $\pm 5\%$ 50WV	1
C130		Styrol 1300pF $\pm 5\%$ 50WV	1
C129		Styrol 4300pF $\pm 10\%$ 50WV	1
C310		Mylar 0.001 μ F $\pm 20\%$ 50WV	1
C133,301		Mylar 0.0022 μ F $\pm 20\%$ 50WV	2
C127,134		Mylar 0.0047 μ F $\pm 20\%$ 50WV	2
C135		Mylar 0.0068 μ F $\pm 20\%$ 50WV	1
C115,307		Mylar 0.022 μ F $\pm 20\%$ 50WV	3
335			
C137,314,315		Mylar 0.033 μ F $\pm 20\%$ 50WV	3
C323		Ceramic 1pF ± 0.25 pF 50WV	1
C312		Ceramic 2pF ± 0.25 pF 50WV	1
C108		Ceramic 3pF ± 0.25 pF 50WV	1
C109,116		Ceramic 5pF ± 0.5 pF 50WV	5
142,145			
336			
C121		Ceramic 6pF ± 0.5 pF 50WV	1
C107		Ceramic 7pF ± 0.5 pF 50WV	1
C126		Ceramic 12pF $\pm 5\%$ 50WV	1
C124,125		Ceramic 15pF $\pm 10\%$ 50WV	3
128			
C106,120		Ceramic 18pF $\pm 5\%$ 50WV	2
C143		Ceramic 30pF $\pm 10\%$ 50WV	1
C325		Ceramic 33pF $\pm 10\%$ 50WV	1
C318		Ceramic 39pF $\pm 10\%$ 50WV	1
C138		Ceramic 70pF $\pm 5\%$ 50WV	1
C111		Ceramic 470pF $\pm 20\%$ 50WV	1
C327,329		Ceramic 0.001 μ F 20% 50WV	3
337			
C330		Mylar 0.01 μ F $\pm 20\%$ 50WV	1
C102,103,112		Ceramic 0.01 μ F +80 —20% 50WV	11
117,118,119			
303,306,317			
319,324			
C113,122,302		Ceramic 0.022 μ F +80 —20% 50WV	10
304,305,309			
313,311,338			
339			
C104,105,110		Ceramic 0.04 μ F +80 —20% 50WV	9
114,139,320			
321,326,331			
RESISTORS			
R111,118		Carbon 10 ohm $\pm 10\%$ 1/4W	3
121			
R129,341		Carbon 15 ohm $\pm 10\%$ 1/4W	2
R120,342		Carbon 56 ohm $\pm 10\%$ 1/4W	2
R340		Carbon 82 ohm $\pm 10\%$ 1/4W	1
R103,104,126		Carbon 100 ohm $\pm 10\%$ 1/4W	9
301,305,307			
310,318,325			
R122		Carbon 180 ohm $\pm 10\%$ 1/4W	1
R320		Carbon 220 ohm $\pm 10\%$ 1/4W	1
R330,332		Carbon 270 ohm $\pm 10\%$ 1/4W	2
R115,302		Carbon 330 ohm $\pm 10\%$ 1/4W	4
314,329			
R303,308		Carbon 390 ohm $\pm 10\%$ 1/4W	2
R106		Carbon 470 ohm $\pm 10\%$ 1/4W	1
R101,317		Carbon 560 ohm $\pm 10\%$ 1/4W	2
R323		Carbon 820 ohm $\pm 10\%$ 1/4W	1
R107,126,304		Carbon 1K ohm $\pm 10\%$ 1/4W	9
309,312,321			
322,333,334			
R125,326		Carbon 1.2K ohm $\pm 10\%$ 1/4W	2
R113,114		Carbon 1.5K ohm $\pm 10\%$ 1/4W	3
130			
R116		Carbon 1.8K ohm $\pm 10\%$ 1/4W	1

PARTS LIST


Key No.	Part No.	Description	Q'ty
PRINTED CIRCUIT BOARD ASSY (TUNER)			
R331,338		Carbon 2.2K ohm $\pm 10\%$ 1/4W	2
R128		Carbon 3.3K ohm $\pm 10\%$ 1/4W	1
R316,335		Carbon 5.6K ohm $\pm 10\%$ 1/4W	3
336			
R117,315		Carbon 10K ohm $\pm 10\%$ 1/4W	4
328,339			
R324		Carbon 12K ohm $\pm 10\%$ 1/4W	1
R102,105,108		Carbon 15K ohm $\pm 10\%$ 1/4W	8
112,306,311			
319,327			
R119		Carbon 18K ohm $\pm 10\%$ 1/4W	1
R124		Carbon 33K ohm $\pm 10\%$ 1/4W	1
R313		Carbon 39K ohm $\pm 10\%$ 1/4W	1
R109,110		Carbon 100K ohm $\pm 10\%$ 1/4W	2
R337		Carbon 1M ohm $\pm 10\%$ 1/4W	1
MECHANISM			
1	141-0-311T-191911	Chassis assembly	1
2	141-2-853T-23400	Plate spring, Cassette pressure	1
3	4-231T-35002	Switch, Power	3
4	141-0-531T-04491	Reel plate assembly, Take up	1
5	123-2-472R-00600	Lug, Earth lead	1
6	141-0-531T-04300	Reel plate assembly, Left	1
7	141-2-811T-04400	Counter	1
8	141-2-851T-62900	Coil spring, Back tension	1
9	141-2-564T-11000	Belt, Counter drive	1
11	4-527T-08300	DC motor	1
12	141-0-661T-66191	Motor pulley assembly	1
13	141-2-378T-07400	Bracket, Motor mtg.	1
14	141-2-421T-16000	Special screw, Motor mtg.	3
15	141-2-445T-11801	Rubber cushion, Motor mtg.	3
16	141-2-371T-06600	Bracket, Transformer mtg.	1
17	141-0-521T-05000	Flywheel assembly	1
18	141-0-521T-05001		1
18	141-0-524T-02400	Bracket assembly, Flywheel	1
19	141-2-457T-04300	Special washer, Flywheel shaft mtg	1
20	141-2-564T-15400	Main belt	1
21	141-0-731T-10300	Slide assembly, Head slide	1
22	141-2-853T-38500	Plate spring, Head slide pressure	1
23	141-0-545T-00700	Lever assembly, Pinch roller mtg.	1
24	141-2-852T-09400	Wire spring, Lever (23) pressure	1
25	141-0-721T-033912	Lever shut off assembly, Auto stop	1
26	4-242T-18700	R/P head	1
27	4-242T-18602	E head	1
28	141-2-461T-17200	Pipe, E head mtg.	1
29	141-2-851T-49700	Coil spring, R/P head adjustment	1
30	123-2-472R-00200	Lug, Head earth	1
31	141-2-472T-02200	Lug, E head lead fixer	2
32	141-2-851T-63100	Coil spring, PLAY slide connection	1
33	141-0-741T-09401	Lever assembly, REW & F.FWD	1
34	141-0-741T-47291	Lever assembly, F.FWD roller	1
35	141-2-851T-63800	Coil spring, Lever (34) returning	3
		Lever (37) pressure F.FWD slide (48) returning	
36	141-2-564T-13500	Belt, F.FWD & REW	1
37	141-0-741T-18000	Lever assembly, Take up roller	1
38	141-2-851T-63900	Coil spring, REC button returning	1
39	141-0-741T-15100	Lever assembly, REW & F.FWD	1
40	4-231T-35002	Switch, F.FWD & REW power	1
41	141-2-365T-27800	Bracket, Switch (40) mtg.	1
42	141-0-731T-09800	Slide assembly, PAUSE button	1
43	141-2-851T-55400	Coil spring, PAUSE button returning	1
44	141-2-731T-24800	Slide, REC button	1
45	141-2-731T-34200	Slide, REW button	1
46	141-0-731T-05700	Slide assembly, PLAY button	1
47	141-2-851T-58700	Coil spring, PLAY button returning	1
48	141-2-731T-34401	Slide, F.FWD button	1
49	141-0-731T-05800	Slide assembly, STOP button	1
50	141-2-741T-79700	Lever, Cassette up	1
51	141-2-851T-56100	Coil spring, Cassette up lever (50)	4
		Slide (49) lever Lever (63) & Lever (61) returning	
52	123-2-472R-00400	Lug, Flywheel earth lead	1
53	141-2-683T-26000	Ring, Cue & Review slide	1
54	141-2-161T-24600	Push button, Except PAUSE button	5
55	141-2-161T-24700	Push button, PAUSE button	1
56	141-0-731T-00605	Slide assembly, Lock slide	1


Key No.	Part No.	Description	Q'ty
MECHANISM			
57	141-2-851T-77000	Coil spring, Lever (72) returning	1
58	141-2-741T-47600	Lever, Record safety lock	1
59	141-2-851T-45400	Coil Spring, Lever (58) returning	1
60	141-0-741T-477911	Lever assembly, Brake	1
61	141-0-741T-15300	Lever assembly, PAUSE	1
62	141-2-683T-25800	Ring, Lever (61) fixer	1
63	141-0-741T-15400	Lever assembly, Head slide operation	1
64	141-2-741T-72600	Lever, REW & F.FWD switch operation	1
65	141-2-851T-28100	Coil spring, Lever (64) returning	1
66	141-2-614T-04700	Lever, PAUSE (61) lock	1
67	141-2-852T-27000	Wire spring, Lever (66) returning	1
68	141-0-737T-00400	Bracket slide assembly	1
69	141-2-851T-77500	Coil spring, Lever shut off (25) returning	1
70	141-2-821T-10200	Tape guide	1
71	141-2-851T-73500	Coil spring, STOP button returning	1
72	141-2-741T-79600	Lever, Auto stop	1
73	131-2-851T-64000	Coil spring, Lock slide (56) returning	1
74	141-2-613T-03000	Frame, Push button guide	1
75	141-2-613T-03100	Frame, Push button guide	1
76	4-264T-06191	Solenoid assembly	1
77	4-231T-50900	Switch, MEMORY REW "ON"	1
78	4-231T-52201	Switch, PLAY - RADIO "OFF"	1
79	141-2-853T-40800	Plate spring, Right reel back tension	1
80	141-2-851T-31500	Coil spring, REW button returning	1
81	141-2-461T-24600	Pipe, Take up roller lever (37) mtg.	1
82	141-2-465T-11900	Stopper, Noise prevention	1
83	141-2-322T-27100	Shield plate, Motor noise prevention	1
MECHANISM SCREWS			
Y1		Pan head screw 2 x 2mm	1
Y2		Pan head screw 2 x 6mm	2
Y3		Pan head screw 2 x 8mm	1
Y4		Pan head screw 2 x 12mm	2
Y5		Flat head screw 3 x 6mm	2
Y6		Tapping screw 2.3 x 6mm	8
Y7		Tapping screw 2.3 x 8mm	3
Y8		Tapping screw 3 x 6mm	4
Y9		Tapping screw 3 x 8mm	3
Y10		Tapping screw 3 x 12mm	1
Y11		Tapping screw 3 x 25mm	2
Y12		Flat head tapping screw 3 x 6mm	1
Y13		Binding head tapping screw 3 x 6mm	1
Y14		Washer 2.3 x 4.3 x 0.4mm	4
Y15		Washer 2.3 x 6 x 0.4mm	3
Y16		Washer 2.6 x 7.3 x 0.5mm	1
Y17		Washer 3 x 7.3 x 0.5mm	1
Y18		Washer 3 x 8 x 0.5mm	2
Y19		Washer 4 x 10 x 0.8mm	1
Y20		Spring washer 2mm	3
Y21		Internal tooth lock washer 2.6mm	1
Y22		External "E" ring 1.5mm	2
Y23		External "E" ring 2mm	3
Y24		External "E" ring 4mm	1
Y25		Graphite nylon washer 2.1 x 4 x 0.13mm	2
Y26		Graphite nylon washer 2.1 x 4 x 0.25mm	2
Y27		Graphite nylon washer 2.1 x 8.5 x 0.25mm	1
Y28		Graphite nylon washer 2.6 x 4.7 x 0.25mm	1
Y29		Graphite nylon washer 2.6 x 4.7 x 0.5mm	1
Y30		Graphite nylon washer 5.2 x 8 x 0.5mm	1
Y31		Steel ball 2mm	4
Y32		Fiber washer 3 x 8 x 0.5mm	1
Y33		Tapping screw with washer 3 x 6mm	2
Y34		Tapping screw with washer 3 x 8mm	2
Y35		Tapping screw with washer 3 x 10mm	2
Y37		Graphite nylon washer 5.2 x 8 x 0.13mm	1
Y38		Vinyl tube 2.5 x 14.5mm	1

EXPLODED VIEW




SCHEMATIC DIAGRAM (TUNER)





SCHEMATIC DIAGRAM (AMPLIFIER)



- S701 ~ S712 : R/P SW
S731 ~ S732 : DOWN AT DIAL LAMP & BATT
METER "ON".
ON AT PLAY MODE.
ON AT REW MODE.
MEMORY SW.
COUNTER SW.
S781 ~ S782 : LOUDNESS SW.
S791 : EARPHONE JACK SW.
S801 ~ S806 : RADIO ON/OFF SW.
S811 : AC/DC SW.
S821 : ON AT PLAY.
S831 ~ S832 : BEAT CANCEL SW.
S841 : AUX JACK SW.
S851 : MIC JACK SW.
S861 : ON AT REW & F. FWD
S871 ~ S872 : TAPE SELECT
SW (NORMAL POSITION)

(1) IC

NO	1	2	3	4	5	6	7	8	9
IC701	P	2.4	0.6	0.02	0.05	0	0	1.05	1.75
RA313	R	2.4	0.6	0.02	0.05	0	0	1.05	1.75
IC702	P	2.2	1.5	0.75	0	0.6	2.5	4.7	-
BA318	R	2.2	1.5	0.75	0	0.6	2.5	4.7	-
IC703	P	0.65	0.1	0.65	0	1.95	5.2	5.9	-
BA306	R	0.65	0.1	0.65	0	1.95	5.2	5.9	-


(2) Q701 ~ Q708

	Q701	Q702	Q703	Q704	Q705	Q706	Q707	Q708
P	B	0.55	0.7	0.8	0.65	4.6	0.65	0.70
	C	1.55	2.0	2.4	5.0	9.0	4.0	8.95
	E	0.05	0.19	0.2	0.06	4.0	0.005	0.01
R	B	0.55	0.7	0.8	0.65	4.0	0.65	0.70
	C	1.52	2.0	2.4	5.0	9.0	4.0	8.9
	E	0.05	0.13	0.2	0.06	4.0	0.005	0.01

(3) Q709 ~ Q710

	Q709	Q710
P	B	0
	C	9.0
	E	0
R	B	0
	C	9.0
	E	0

WIRING DIAGRAM (AMPLIFIER)



[illegible]